

FIG.1

FIG.2




FIG.3A PRIOR ART

STOP COMMAND PLAYBACK COMMAND

CHANNEL PAUSE IDLE STOP SWITCH STOP IDLE PAUSE

FIG.3B

PLAYBACK
CHANNEL
PAUSE IDLE SWITCH IDLE

FIG.4 PRIOR ART

CHANNEL 1	CHANNEL 2	EXTERNAL INPUT	CHANNEL 1

FIG.5 PRIOR ART

